



## Accessories Adjustable Stop Screws AS-U|AS-W



Adjustable Stop Screws AS-U

| Description      | Order-No.   | G       | SW1 | SB  | L1 | for Collet Chucks       |
|------------------|-------------|---------|-----|-----|----|-------------------------|
| AS-CP11-U        | 44981000100 | M8x1    | 4   | 1,6 | 8  | CP11M•CPC11M            |
| AS-CP16-U        | 44982000100 | M11x1   | 6   |     |    | CP16M•CPC16M•CP16•CPC16 |
| AS-CP20-U        | 44983000100 | M14x1   | 5   | 1,5 |    | CP20                    |
| AS-CP25/32/225-U | 44984000101 | M18x2,5 | 6   | 1,6 | 10 | CP25•CP32•CP225DG       |
| AS-CP25-U        | 44984000102 | M18x1,5 |     |     |    | CP25                    |
| AS-CP32/225-U    | 44984000103 | M22x1,5 |     |     |    | CP32•CP225DG            |
| AS-CP40-U        | 44985000100 | M28x1,5 |     |     | 25 | CP40                    |



Adjustable Stop Screws AS-W

| Description      | Order-No.   | G       | SW1 | SB  | L1 | L2 | D    | for Collet Chucks       |
|------------------|-------------|---------|-----|-----|----|----|------|-------------------------|
| AS-CP11-W        | 44981000200 | M8x1    | 4   | 1,2 | 8  | 18 | 4,5  | CP11M•CPC11M            |
| AS-CP16-W        | 44982000200 | M11x1   |     |     |    | 22 | 7    | CP16M•CPC16M•CP16•CPC16 |
| AS-CP25/32/225-W | 44984000201 | M18x2,5 | 6   | 1,6 | 10 | 28 | 10,5 | CP25•CP32•CP225DG       |
| AS-CP25-W        | 44984000202 | M18x1,5 |     |     |    |    |      | CP25                    |
| AS-CP32/225-W    | 44984000203 | M22x1,5 |     |     |    |    |      | CP32•CP225DG            |

## Accessories Taper Wipers KWK



### Taper Wipers KWK-ER

| Description | Order-No. | for Chucks and Holders Type |
|-------------|-----------|-----------------------------|
| KWK-ER11    | 2220100   | CP11M•CPC11M                |
| KWK-ER16    | 2220200   | CP16•CPC16•CP16M•ST16-GB    |
| KWK-ER20    | 2220300   | CP20•ST20-GB                |
| KWK-ER25    | 2220400   | CP25•ST25-GB                |
| KWK-ER32    | 2220500   | CP32•ST32-GB                |

## Accessories Coolant Supply Tubes and Wrenches IKR|SCHL-IKR



### Coolant Supply Tubes IKR

| Description | Order-No. | for HSK | Form    | G       |
|-------------|-----------|---------|---------|---------|
| IKR-HSK25   | 2490200   | 25      | A and E | M8x1    |
| IKR-HSK32   | 2490300   | 32      |         | M10x1   |
| IKR-HSK40   | 2490400   | 40      |         | M12x1   |
| IKR-HSK50   | 2490500   | 50      |         | M16x1   |
| IKR-HSK63   | 2490600   | 63      |         | M18x1   |
| IKR-HSK80   | 2490700   | 80      |         | M20x1,5 |
| IKR-HSK100  | 2490800   | 100     |         | M24x1,5 |



### Wrenches SCHL-IKR for Coolant Supply Tubes

| Description     | Order-No. | for HSK |
|-----------------|-----------|---------|
| SCHL-IKR-HSK25  | 2492200   | 25      |
| SCHL-IKR-HSK32  | 2492300   | 32      |
| SCHL-IKR-HSK40  | 2492400   | 40      |
| SCHL-IKR-HSK50  | 2492500   | 50      |
| SCHL-IKR-HSK63  | 2492600   | 63      |
| SCHL-IKR-HSK80  | 2492700   | 80      |
| SCHL-IKR-HSK100 | 2492800   | 100     |